



SPARE PARTS LIST  
ELECTRIC WATER HEATER

Models

**EUREKA 2000 W T**

**EUREKA 2000 W C**

---


Edition 2

Current from 4120245 to -----



Add to Edition 1

ER2001430000502001



MODEL	CODE	SERIAL NO. VALIDITY	REF.
EUREKA 2000 W T	410793	41020245	A
EUREKA 2000 W C	410631	41020245	B

ER2001430000502001

<b>PART.</b>	<b>CODE</b>	<b>DESCRIPTION</b>	<b>REF.</b>	<b>NOTE</b>
1	410656	Wall bracket		
2	410658	Thermostat RTN 300		
3	410659	Fixing plate (element)		
4	410738	Spout	B	
5	410660	Thermofuse		
6	410661	Neon on/off switch		
7	410662	Switch cap		
8	410663	Cable (power supply)	A	
8	411265	Cable (power supply)	B	
9	410674	Heat warning neon		
10	411167	Signal lamp		
11	411379	Safety valve		
12	411380	Back nut		
13	410746	Plastic cover		
14	410666	Lever assembly		
15	410667	Valve body retaining cap		
16	411251	Flow limiter (D. 3mm 1/2"- 3/8")		
17	411373	Valve body		
18	411374	Ceramic disc cartridge		
19	410670	Ceramic disc bush		
20	570118	O Ring (element)		
21	816745	Element (2000W - 230V)		
22	410673	O Ring (valve body)		
101	573266	Cable clamp		11

<b>NOTE</b>	<b>DESCRIPTION</b>
11	Not illustrated