



SPARE PARTS LIST  
ELECTRIC WATER HEATER

Models

**EP 10 O**


**EP 15 O**

---

Edition 1

Current from Serial No:- 000419 to -----





ER2000830014301001

MODELS	CODE	SERIAL NO. VALIDITY	REF.
EP 10 O	868289	000419	A
EP 15 O	868291	000419	B

<b>PART.</b>	<b>CODE</b>	<b>DESCRIPTION</b>	<b>REF.</b>	<b>NOTE</b>
1	574305	Anode (magnesium M4 14x155)		
2	810830	Element (3000W-230V)		
3	570016	Flange gasket		
4	570024	Flange bracket		
5	570063	Terminal (earth)		
6	570078	Screw (tapping M4x8)		
7	570069	Retaining nut (Heating element)		
8	570074	Plastic cover retaining screw		
9	570164	Knob (control)		
10	573070	Neon lens		
11	570163	Cover		
12	570077	Neon lamp and wiring		
13	570029	Cap (regulation)		
14	691599	Thermostat		
15	572447	Safety valve (6 bar)		
16	571397	Dielectric Junction (1/2")		
17	570341	Heater wall hanging bracket		

<b>NOTE</b>	<b>DESCRIPTION</b>

ER2000830014301001